
FITTING INSTRUCTIONS



- 1. Place the parcel box in the desired place.
- 2. Open the box and mark the holes from the inside with a
- 3. Remove the parcel box to reveal the marked holes
- 4. Obtain a 10mm drill bit and drill down 80mm in depth
- 5. Clean the hole of dust and place bolt in ground
- 6. Remove nut and washer and place the parcel drop box on top
- 7. Screw down the nut to leave the parcel box fixed in place.

Never miss a delivery again

Parcel-drop-box©

